U-BOAT



#### DEAR CLIENT,

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH. IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE, THE TECHNICAL DETAILS AND THE WARRANTY BOOKLET. WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.



## WATCH FUNCTIONS.

# A CAP CROWN

B SCREW IN CROWN

C HOUR HAND


D MINUTE HAND

E SECOND HAND


G DATE (if fitted)

F 24 HOUR INDICATOR (if fitted)

H UNIDIRECTIONAL BEZEL (if fitted)



REPRESENTATIVE IMAGE. SOME COMPONENTS MAY BE IN DIFFERENT POSITIONS OR NOT FITTED.



## INSTRUCTIONS FOR USE.

1. Unscrew the cap crown A to gain access to the crown B.

 $\begin{array}{c} \textbf{POSITION 1} \\ \textbf{unscrew the crown } \textbf{B} \text{ to wind and start the watch.} \\ \textbf{NEUTRAL POSITION} \end{array}$ 

**POSITION 2** carefully pull the crown **3** right out to the first click. Turn the crown **3** clockwise to set the date **6** (if fitted).

**POSITION 3** carefully pull the crown **B** right out to the second click and turn the crown **B** to set the exact time.

Use indicator **G** (if fitted) for correct date change **G** (if fitted).

Fully depress the crown is to move it back into the neutral position and gently screw is it in. Screw in the cap crown is until firmly in place.
The bezel is (if present) rotates in a counterclockwise direction.



### CARE AND MAINTENANCE.

The precision mechanism in your watch will provide long-lasting performance when properly cared for.

We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap.

Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

Remember to rinse the watch after it comes into contact with seawater.

Automatic watches require manual winding following a long period of inactivity.

#### **U-BOAT HEAD OFFICE**

Via per San Gennaro, 13 Gragnano, Capannori - 55012 Lucca - Italy Tel: +39 0583 469288 - Fax: +39 0583 462249 service@u-boatwatch.com