U-BOAT

ITALO FONTANA



DEAR CLIENT.

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.
IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE, THE
TECHNICAL DETAILS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH
ON OUR OFFICIAL WEB SITE

IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.



WATCH FUNCTIONS.

- A CROWN
- B BEZEL CROWN
- C BEZEL DUAL TIME
- D HOUR HAND
- D1 DUAL TIME HAND
- E MINUTE HAND




REPRESENTATIVE IMAGE.
SOME COMPONENTS MAY BE IN DIFFERENT POSITIONS OR NOT FITTED



INSTRUCTIONS FOR USE.

- 1. Unscrew the crown **A** and pull it out to bring it into the position 2.
- 2. Turn the crown **A** to set the exact time.
- 3. Push down and screw in the crown **A** back into position 1.



INSTRUCTIONS FOR DUAL TIME SETTING

Pull out the crown **B**.

Rotate the bezel **C** to set the second time. (check **D**) dual time hand).

Fully depress the crown **B** to move it back into the neutral position.



BATTERY REPLACEMENT AND OIL ADJUSTMENT

- 1. Innovative closure system with a compartment for quick battery change.
- Closing system for oil regulation- do not access, this operation is to be executed exclusively by U-BOAT specialized technicians.

CARE AND MAINTENANCE. The precision mechanism in your watch will provide long-lasting performance when properly cared for. We recommend taking your watch to an Authorised Retailer Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts. We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap. Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields. Remember to rinse the watch after it comes into contact with seawater. We suggest pulling out the crown when the watch is not being used for a long period of time in order to limit battery consumption. We advise taking your watch to an Authorised Retailer / Authorised Service Centre to replace the battery. Optimal operating conditions 0°/+60°C when not work.